

UTILITY TRACK VEHICLE



Harsco Rail's Utility Track Vehicles are engineered to order, meeting the customer's specifications with numerous available options. Harsco Utility Track Vehicles provide a multi-functional use that is instrumentally valuable on the track. Contact Harsco Rail for further information on vehicle options.

UTILITY TRACK VEHICLE

Specifications

All Harsco Rail Utility Track Vehicles (UTV) are custom built. Upon request, many of the accessories listed below can be added to individual customer's UTVs. Various accessories are not configurable to other accessories. Harsco Rail has manufactured Utility Track Vehicles with expert engineering since the 1980's.

Engine

- 300-500 HP Engine
- Other

Transmission

- 4-Speed Power Shift Transmission
- Hydrostatic Drive

Final Drive Configurations

- One powered bogie; one idler bogie
- Two powered bogies
- Axle, Axle

Accessories

- Crane
- Platform scissor lift
- Outriggers
- Hydraulic and air powered tool circuits
- Welding equipment
- Oxy-acetylene tank racks
- Snow plow
- Couplers for towing capability
- Storage units
- Generator
- Remote operator cab on rear



Technology Options

COMPASS™

- Provides visibility into fleet location and historical machine movement
- Generates maintenance and production reports
- Compares productivity across the fleet
- Automates data entry and reporting data

Jupiter II Control System

- Comprehensive diagnostics
- Simplified electrical troubleshooting
- Improved reliability
- Scalable platform
- Operator interface via computer touchscreen

Download full specs at www.harscorail.com
Watch video at www.youtube.com/user/harscorail

Harsco Rail

2401 Edmund Rd., Box 20
Cayce-West Columbia, SC 29171-0020

Tel: (803) 822-9160
Fax: (803) 822-8107
Email: railinfo@harscorail.com
www.harscorail.com

HARSCO
RAIL



Bulletin #UTV-01S-0513
Printed in USA, May, 2013

Harsco Rail, Harsco Corporation Facility Locations:

2401 Edmund Road
Box 20
Cayce-West Columbia, SC
29171-0020
Tel: (803) 822-9160
Fax: (803) 822-8107

415 North Main St.
Fairmont, MN 56031-1837
Tel: (507) 235-3361
Fax: (507) 235-7370

200 S. Jackson Rd.
Ludington, MI 49431
Tel: (231) 843-3431
Fax: (231) 843-4830

900 Kings Highway North
Suite 208
Cherry Hill, NJ 08034
Tel: (856) 779-7795
Fax: (856) 779-7431

4 Strathwyn St.
P.O. Box 5287 Brendale
Queensland 4500, Australia
Tel: 61 7 3205 6500
Fax: 61 7 3205 7369

Unit 1, Chewton Street, Eastwood
Nottingham NG16 3HB
United Kingdom
Tel: 01773 539480
Fax: 01773 539481

Av. Marechal Camara
160 Grupo 1901
Centrol CEP: 20020-080
Rio de Janeiro-RG
Tel: (21) 2510-5151
Fax: (21) 2224-3484

Harsco Rail Europe GmbH
Rehhecke 80
40885 Ratingen
Germany
Tel: +49 2102 937200
Fax: +49 2102 37651

Harsco APAC Rail Machinery Trading
(Beijing) Co. Ltd.
Room 805, State Guest Mansion
No. 11 Fuwai Ave.
100037 Beijing, China
Tel: +8610-6800-3286
Fax: +8610-6800-3288

The HARSCO RAIL equipment pictured in this brochure is intended to illustrate the general appearance and features of this product. It is equipped as specified by a particular customer and may or may not show items that are optional or recommended by HARSCO RAIL, Harsco Corporation. Specifications, illustrations, and descriptive materials herein were accurate as known at the time this publication was approved for printing. HARSCO RAIL, Harsco Corporation reserves the right to discontinue models or options at any time or change specifications and materials, equipment and design without notice and without incurring obligation. Federal, State or Provincial, and/or local laws and regulations may require additional equipment for the particular use intended for this product. It is the buyer's responsibility to determine the applicability of such laws and regulations to the buyer's intended use for the product and to arrange for the installation of the required equipment. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies and/or mark holders.